

JZD Pendant Lamp Installation Instructions

Thank you for your purchase! These conical lamps require that you use a maximum 60 watt incandescent light bulb. With current laws moving lighting into the realm of alternative, more environmentally safe bulbs, there are many directions one can go with regard to bulb choice. If you choose a bulb alternative to the bulb provided, please consult with your electrician about options. Also, your local hardware store clerk will be able to offer suggestions. Please ask for 'wattage equivalents' to 60 watt incandescent when selecting an alternate bulb.

The Lamp should be installed by a licensed electrician. We've provided a few items to help with this:

- A canopy (or escutcheon) has been provided in a white finish. Feel free to have your contractor paint this to match your ceiling. They may want to use a primer first. This can certainly be done after the light is installed.
- A small tube of super glue.
- A clothespin.

The leather cover on the cord has been purposely cut long because leather can shrink over time. Also, for wiring purposes, it's better to have some excess leather so there's a little 'play'. The leather can be 'scrunched' a bit to be sure there's ample covering at the bottom near the lamp and also at the top under the ceiling canopy.

Once the lamp has been wired into the box and the leather cover slid up and screwed into the box, there will be exposed cord. If you pull the leather back by sliding it down, there will be a silver mark on the cord marking the 'drop dimension'. This mark should align with the bottom of the canopy. The $\frac{3}{4}$ " depth of the canopy has been taken into account. The installer can now:

- 1) Spread a small but ample amount of super glue around the top of the electrical cord, just under the bottom of the canopy, about $\frac{1}{2}$ " down onto the cord, and all the way around.
- 2) Pull up the leather and 'scrunch' it a little up against the canopy so that if there is any 'slippage' or 'shrinking' of the leather over time, it will have some excess to compensate for those things.
- 3) Place the clothespin carefully onto the leather cover over the glued area and allow to dry for an hour or so.
- 4) Remove Clothespin.
- 5) FYI: super glue can be removed from skin using acetone. (This can be purchased at a hardware store).
- 6) The porcelain enamel on spun steel shade will retain its sheen through years of use, and is easily cleaned with water and mild soap.